























*Polymer/Epoxy Grout*

311 White	
101 Ivory	
102 Almond	
103 Silk	
104 Beige	
105 Lt. Camel	
106 Antique White	
107 Parchment	
108 Sand Stone	
109 Jaisalmer	
110 Golden Yellow	

*Polymer/Epoxy Grout*

211 Wooden	
206 Mayan Red	
207 Sable/Dark Brown	
208 Mocha	
209 Terracotta	
210 Signal Red	
301 Sky Blue	
302 Alpine Blue	
303 Sapphire	
304 Aquamarine	
305 Dark Green	

111  
Golden Brown



201  
Marble Beige



202  
Spectra Pink



203  
Rust



204  
Brown/Quarry Red



205  
Burgandy



Special shades can be supplied on request.

306  
Silver Shadow



307  
Smoke Grey



308  
Slate Grey



309  
Platinum



310  
Raven



311  
Midnight Black



Shades are for Indication purpose only.

### How to Use Cement Base Grout



1 Add 3 to 3.5 parts of Home Pride Tile Grout to one part of water by volume.



2 Mix to a smooth consistency.



3 Fill the tile joints by spreading filler paste with rubber trowel such that the entire area of joint gaps are filled.



4 Remove surplus Home Pride Tile Grout with a damp sponge. Allow 24 hours to dry.

### How to Use Epoxy Grout (1Kg. Epoxy)



1 Mix 200 gm. of Resin to 100 ml. of Hardner.



2 Add Filler Until Homogeneous paste is obtained.



3 With the help of a Squeeze trowel fill the tile joints.



4 Clean the tiles with a wet hard sponge immediately. Remove the excess material from tile. Allow to dry before using.

Note :- Use within 30 minutes after mixing resin Hardner filler.